

# HP4 Lüfterrad / HP4 Flywheel (Art.-Nr. 5001000 / 5001120)



Um das Lüfterrad zu demontieren muss zuerst die Lüfterradabdeckung abgeschraubt werden. Nun die Polradmutter mit einer 19er Nuss öffnen. Lüfterrad gegen mitdrehen sichern, Haltewerkzeug verwenden! (Art. 20095100). Nun mit einem passenden Abzieher (Art. 933300) das Lüfterrad demontieren. Bevor das HP4 aufgesetzt wird erst den Konus reinigen und das Gewinde leicht fetten. Nun das Lüfterrad, dann die Sicherungsscheibe und dann die Mutter auf die Kurbelwelle setzen. Diese mit 60 – 65 Nm festziehen. Zuletzt die Lüfterradabdeckung wieder montieren.

**ACHTUNG: Position der Nut beachten!**  
(siehe Abbildung)

In order to dismantle the flywheel it is at first necessary to unscrew and take off the flywheel cover. Now unlock the flywheel nut with a 19mm bolt of a lock. Secure flywheel against rotating simultaneously by using holding tool (Art. 20095100). Remove flywheel by using a fitting flywheel removal tool (Art. 933300). Clean cone and slightly grease thread before putting on the HP4. Now put the flywheel, then the securing washer and the nut on the crankshaft. Tighten nut by 60 – 65 Nm. Finally, remount the flywheel cover.

**ATTENTION: Pay attention to the notch! (see illustration)**

